

## Hidrostat

### Hidrostat

**10.60.030**



HD 505 EA 101  
Broj kontakata: 7

Nivo II (Off/On) 230 ÷ 160  
Nivo I (Off/On) 170 ÷ 130  
Sigurnosni nivo (Off) 300  
Metalflex, Slovenija

### Hidrostat

**10.60.040**



HD 505 AJ 101  
Broj kontakata: 3

Nivo (Off/On) 200 ÷ 160  
Metalflex, Slovenija

### Hidrostat

**10.60.050**



HD 505 CH 101  
Broj kontakata: 6

Nivo I (Off/On) 170 ÷ 130  
Nivo II (Off/On) 210 ÷ 160  
Metalflex, Slovenija

### Hidrostat

**10.60.060**



HD 528 V5CC  
Broj kontakata: 7

Gorenje šifra: 618672  
Nivo I (On/Off) 120 ÷ 160  
Sigurnosni nivo (Off) 300  
Nivo II (On/Off) 150 ÷ 190  
Metalflex, Slovenija

### Hidrostat

**10.60.061**



HD 528 G5CC  
Broj kontakata: 7  
Gorenje šifra: 598509  
Nivo I (On/Off) 115 ÷ 150  
Sigurnosni nivo (Off) 300  
Nivo II (On/Off) 160 ÷ 200  
Metalflex, Slovenija

### Hidrostat

**10.60.070**



HD 505 ET 101  
Broj kontakata: 7  
Gorenje šifra: 618671  
Nivo II (Off/On) 190 ÷ 150  
Nivo I (Off/On) 160 ÷ 120  
Sigurnosni nivo (Off) 300  
Metalflex, Slovenija

### Hidrostat

**10.60.071**



HD 505 EP 101  
Broj kontakata: 7  
Gorenje šifra: 618670  
Nivo I (Off/On) 110 ÷ 80  
Nivo II (Off/On) 130 ÷ 95  
Sigurnosni nivo (Off) 300  
Metalflex, Slovenija

### Hidrostat

**10.60.073**



HD 505 GA 201  
Broj kontakata: 4  
za Gorenje šifru: 587573  
Nivo (On/Off) 105 ÷ 75  
Sigurnosni nivo (Off) 300  
Metalflex, Slovenija

### Hidrostat

**10.60.600**



TG-600  
250.03301.10A

16 A / 250 V~  
T&G, Italija