



LTB

LTB-10A-10P




Type	Form	L	L1	L2	W	H	Screw
LTB-10A-10P	10A-10P	100	91	8	26	19	M3x7

LTB-20A-3P /4P /6P /10P




Type	Form	L	L1	L2	W	H	S
LTB-20A-3P	20A-3P	50.5	42.5	8	30	22.2	M
LTB-20A-4P	20A-4P	61	52	8	30	22.2	M
LTB-20A-6P	20A-6P	82	74	8	30	22.2	M
LTB-20A-10P	20A-10P	123.8	115.5	8	30	22.2	M

LTB-20A-12P / 15P /20P



Type	Form	L	L1	L2	W	H	Screw
LTB-20A-12P	20A-12P	145	136.5	8	30	22.5	M4x8
LTB-20A-15P	20A-15P	177.3	167.5	8	30	22.5	M4x8
LTB-20A-20P	20A-20P	230	220	8	30	22.5	M4x8

LTB-30A-3P /4P /6P



Type	Form	L	L1	L2	W	H
LTB-30A-3P	30A-3P	56.4	47	10	32	22.7
LTB-30A-4P	30A-4P	68.9	59.5	10	32	22.7
LTB-30A-6P	30A-6P	94	84.5	10	32	22.7



EL

News

Ελεγκτικό
Electrolux
Macedonia
Palenzo

LTB-30A-10P /12P

LTB-45A-10P





Type	Form	L	L1	L2	W	H	Screw
LTB-30A-10P	30A-10P	144.4	136	10	32	22.7	M4×8
LTB-30A-12P	30A-12P	170	161.8	10	32	22.7	M4×8



Type	Form	L	L1	L2	W	H
LTB-45A-10P	45A-10P	172	163.5	12	36.2	23.2

LTB-60A-3P



LTB-60A-4P



Type	Form	L	L1	L2	W	H
LTB-60A-3P	60A-3P	82.8	28	16	40	34
LTB-60A-4P	60A-4P	110	28	16	40	34

LTB-100A-3P**LTB-100A-4P**

Type	Form	L	L1	L2	W	H
LTB-100A-3P	100A-3P	105	36.5	22	55	40
LTB-100A-4P	100A-4P	138	36.5	22	55	40

LTB-150A-3P**LTB-150A-4P**

Type	Form	L	L1	L2	W	H
LTB-150A-3P	150A-3P	113	38	24	66	43
LTB-150A-4P	150A-4P	150.3	38	24	66	43

